














QUICK REFERENCE GUIDE: ADEMCO PRO ALARM PANEL

FUNCTION	BUTTONS TO PRESS	RESULT
ARM PERIMETER (STAY)	*ENTER USER CODE *PRESS 	*THREE BEEPS WILL SOUND *ARMED "STAY" MESSAGE DISPLAYED * ARMED LIGHTS WILL BE LIT
ARM PERIMETER WITH NO DELAY (INSTANT STAY)	*ENTER USER CODE *PRESS 	*NO ENTRY DELAY ON DOORS *THREE BEEPS WILL SOUND *ARMED "STAY" MESSAGE DISPLAYED * ARMED LIGHTS WILL BE LIT
ARM ENTIRE SYSTEM (AWAY)	*ENTER USER CODE *PRESS 	*TWO BEEPS WILL SOUND *DISPLAY SHOWS "AWAY" * ARMED LIGHTS WILL BE LIT
DISARM SYSTEM	*ENTER USER CODE *PRESS 	* READY LIGHT WILL BE LIT *A SINGLE TONE WILL SOUND
BYPASS ZONE(S)	*ENTER USER CODE *PRESS  *ENTER ZONE NUMBERS (NOTE: SINGLE DIGIT ZONES NEED TO BE PRECEDED BY A "0")	*KEYPAD WILL MOMENTARILY DISPLAY "BYPASS" MESSAGE FOR EACH BYPASSED ZONE NUMBER. *ALL SENSORS SHOWING OPEN WILL BE NOW BE BYPASSED *ARM SYSTEM AS USUAL
SEND EMERGENCY, MEDICAL OR FIRE ALARM ACTIVATION	*PRESS AND HOLD THE ASSIGNED BUTTON FOR TWO SECONDS	*THE APPROPRIATE AGENCY WILL BE DISPATCHED
TURN CHIME ON/OFF	*ENTER USER CODE *PRESS 	*CHIME WILL TURN ON/OFF
VOICE ANNUNCIATION ON/OFF	*PRESS  +  +  + 	*ON: FAULTED ZONES CAUSE A VOICE STATUS ANNOUNCEMENT, CHIME AND DISPLAY *OFF: SOUNDER STILL PROVIDES CHIME IF NORMAL CHIME MODE IS ON
CANCEL/SILENCE ALARM	*ENTER USER CODE *PRESS 	*ALARM IS CANCELLED & SILENCED * READY LIGHT WILL BE LIT *A SINGLE TONE WILL SOUND
RESET SMOKE DETECTORS	1) PRESS  2) ENTER USER CODE +  TWICE	1) SILENCES ALARM 2) CLEARS KEYPADS MEMORY OF ALARM DISPLAY

Moore Protection Inc.

318 Avenue I #819 Redondo Beach, CA 90277

Phone: (310) 540-7229 • Fax: (310) 540-7252 • Email: inquiries@mooreprotection.net

www.mooreprotection.net

ACO #: 5965