



QUICK REFERENCE GUIDE:

Gemini Alarm Panel

Arming System:

*Make sure all windows/doors are secured

*Green light on keypad should be lit & display should show "SYSTEM READY"

While Home:

*Push **INTERIOR** button, enter user code, then push **ON/OFF** button

*Note: This will enable free movement with the home while the perimeter zones are maintained

While Home with no delay on doors (Instant Mode):

*Enter user code and push **ON/OFF** button

*Push **INSTANT** button after arming

While Away:

*Enter user code and push **ON/OFF** button

*Exit premises within the "EXIT TIME XXX"

Disarming System:

*Enter premises through the Entry/Exit door(s)

*Enter user code, then push **ON/OFF** button (Note: Red light should go off)

Bypassing/Un-Bypassing Zones:

*Push **BYPASS** button and then the zone # the user would like to bypass/un-bypass

Silencing and/or Deciphering Audible Alarms:

*Enter user code and then push **ON/OFF** button

*Note: If keypad displays "FIRE ALARM" or "FIRE TROUBLE", in order silence keypad sounder push **RESET**

*Note: If keypad displays "SYSTEM TRBL" and you cannot correct the problem immediately, push the **RESET** button which will enable you to still arm system

Activating/Deactivating Door Chimes:

*Push **FUNCTION** button until "ACTIVATE CHIME" or "DEACTIVATE CHIME" is displayed, push Yes/**INTERIOR** button

Moore Protection Inc.

318 Avenue I #819 Redondo Beach, CA 90277

Phone: (310) 540-7229 • Fax: (310) 540-7252 • Email: inquiries@mooreprotection.net

www.mooreprotection.net

ACO #: 5965