

QUICK REFERENCE GUIDE

Panel Type: GE NX-8
Keypad Type: 148-E



Moore Protection, Inc.
318 Avenue I #819
Redondo Beach, CA 90277
Phone: (310)540-7229
Fax: (310)540-7252
inquiries@mooreprotection.net
www.mooreprotection.net
ACO #: 5965

<u>FUNCTIONS</u>	<u>INSTRUCTIONS</u>	<u>RESULTS</u>
ARM PERIMETER (STAY)	◆PRESS "STAY" BUTTON	◆DISPLAY WILL READ "SYSTEM ARMED" ◆ARMED AND STAY LIGHTS WILL BE LIT
ARM PERIMETER WITH NO DELAY (INSTANT STAY)	◆PRESS "STAY" BUTTON TWICE	◆NO ENTRY DELAY ON DOORS
ARM ENTIRE SYSTEM (AWAY)	◆ENTER EXIT BUTTON	◆DISPLAY WILL READ "SYSTEM ARMED" ◆EXIT TONE WILL BEGIN TO COUNTDOWN ◆LEAVE PREMISES WHILE DELAY IS ACTIVE ◆AT THEN END OF THE EXIT DELAY THE SYSTEM WILL BE FULLY ARMED AWAY
DISARM SYSTEM/ CANCEL AN ALARM	◆ENTER USER CODE	◆DISPLAY WILL READ "SYSTEM READY" ◆ARMED LIGHT WILL GO OFF
BYPASS ZONE(S)	1) PRESS * BUTTON AND UP ARROW BUTTON TO SCROLL TO FIND THE ZONE(S) YOU WANT BYPASSED 2) PRESS "BYPASS" BUTTON WHILE ZONE IS DISPLAYED 3) PRESS "BYPASS" BUTTON TWICE TO EXIT THIS FUNCTION	1) ZONE DESCRIPTIONS WILL BE DISPLAYED 2) BYPASS LIGHT WILL FLASH 3) BYPASS LIGHT WILL STOP FLASHING
TURN CHIME ON/OFF	◆PRESS "CHIME" BUTTON	◆CHIME LIGHT WILL TURN ON/OFF
TESTING THE SYSTEM	◆PRESS * BUTTON AND "4" BUTTON ◆ENTER USER CODE TO SILENCE THE SIREN	◆THE SYSTEM WILL TEST THE SIREN, BATTERY AND COMMUNICATOR
SEND AN EMERGENCY, MEDICAL OR FIRE ALARM ACTIVATION	◆PRESS AND HOLD THE POLICE BUTTON, MEDICAL BUTTON OR FIRE BUTTON FOR TWO SECONDS	◆SIREN WILL SOUND ◆EMERGENCY, MEDICAL OR FIRE ALARM SIGNAL WILL BE SENT TO THE MOORE PROTECTION CENTRAL STATION
RESET SMOKE DETECTORS, ZONES TROUBLES AND ZONE TAMPERS	◆DISARM THE SYSTEM IF ARMED ◆PRESS * BUTTON AND "7" BUTTON	◆SMOKE DETECTORS, TAMPERS AND TROUBLES WILL RESET
CHANGE USER CODES	◆PRESS * BUTTON AND "5" BUTTON ◆ENTER USER CODE ◆ENTER 3-DIGIT USER NUMBER (I.E. "003" FOR USER 3) ◆ENTER IN NEW USER CODE ◆TO EXIT FUNCTION PRESS * BUTTON	◆NEW USER CODE WILL TAKE AFFECT